

# Snap Band Installation

*Workers should be familiar with and follow the manufacturers' guidelines for Dust Collector Operation and Maintenance as well as applicable OSHA and MSHA guidelines for confined entry and equipment and electrical lockouts before attempting any work on a bag house.*

**1.**



Insert Filter bag through hole in cell plate.

**2.**



Hold bag just below snap ring while pushing through being careful not to scrape the bag.

**3.**



Pre-shape the snap band into a kidney bean shape

**4.**



Place the snap band groove into the cell plate setting the seam of the bag first.

**5.**



Release snap band.

**6.**



Make sure the seal is even and the bag does not spin within the cell plate.